

KYRON HInstallation Instructions

H Install

 \triangle

Before starting: Make sure all firearms are unloaded and safe. Please read all instruction manuals for suppressor and firearm.





STANDARD HUB INSTALLATION

1 Remove the HUB Adapter

Remove hub adaptor from suppressor body using proper wrench. (spanner)

Using a padded vise or leather strip on vise jaws to protect suppressor will assist in removal. (Some suppressors come with two spanners to remove the HUB mount without a vice).

Note: There may be a thread locker that requires heat for removal.








2 Attach the Kryon H Adapter

Once removed install the **Kryon H** adapter onto your HUB mount with the threads facing forward.





3 Rei

Reinstall the HUB Mount

Install the HUB mount with the **Kryon H** adapter onto the suppressor body. Make sure to center the Kryon H adapter before tightening.

(Photo below shows suppressor not centered)





OPTIONAL: TIMING THE KRYON SHROUD

It is possible to time/select a desired position of the Kryon shroud once it's installed to the ${\bf Kryon}\,{\bf H}$ adapter.

1

Thread the Shroud

Thread the Kryon shroud onto the **Kryon H** adapter, making sure to fully seat the shroud onto the Kryon H adapter.



Mark Reference Point

To time the Kryon shroud mark the back of the Kryon H adapter with a sharpie/pencil or piece of tape. Note: We like to use the Guntology logo as a reference point.



Set Desired Timing

Determine your desired position for the logo (3,6,9,12 o'clock.) Loosen the HUB mount and rotate the Kryon H adapter to align the mark you made to your desired position then tighten the HUB mount in place, ensuring the Kryon H adapter remains centered.



Before Firing: Always check for proper suppressor alignment on the host firearm.



Questions or concern Please reach out to: Support@Guntology.com



OPTIONAL: KRYON H INSTALL ON DIRECT THREAD HUB

Kryon H adapter may also be installed onto a direct thread mount.





1 Install Direct Thread Mount

Install the direct thread mount and tighten onto suppressor.





2 Thread Suppressor onto Muzzle



3 Mark Top Dead Center

Mark the top center of the suppressor and install the Kryon shroud.





Mark Adapter Reference

Mark the back of the Kryon H adapter using the Guntology logo as a reference point.



Remove Components

Remove both the Kryon shroud and suppressor.



Align Index Marks

Loosen the direct thread mount and line up your index marks.



Reinstall Components

Kryon H adaptor is centered on HUB



8

Final Tightening

Once properly aligned and centered, tighten fully onto the suppressor body.



Thread onto Muzzle






10

Reinstall the Shroud

Installation is complete when the Guntology logo (or your reference mark) is at the desired position.







Before Firing: Please always- check for proper alignment of suppressor on host firearm.

If alignment is incorrect, do not fire the weapon — please contact Guntology LLC for further assistance.









GUNTOLOGY WARRANTY

Coverage for **KRYON**™ **H**, **C**, and **F** Models

WARRANTY COVERAGE

Guntology stands behind every KRYON™ System component—including the H, C, and F models—with a lifetime warranty for the original owner. If a defect in materials or workmanship is found, we will repair, replace, or refund the original purchase price at our discretion.

This warranty does not apply to:

- → Expected wear over time
- → Damage caused by misuse, abuse, or neglect
- → Unauthorized modifications or non-factory repairs
- → Use with out-of-spec or non-SAAMI/NATO ammunition
- → Incorrect installation or handling
- → Corrosive exposure thermal damage or impact-related harm

Should service be required due to any of the above, we'll provide a quote before any work begins. Use of the **KRYON** System outside its intended design may void this warranty.

LIFETIME WARRANTY NOTICE

Guntology proudly offers a lifetime warranty to the original owner on all **KRYON™** System components. This warranty applies to defects in materials and workmanship under normal, intended use.

⚠ Please note: This warranty does not cover damage resulting from excessive or obvious abuse,neglect, unauthorized modifications, or operation outside of intended use—as detailed in this manual.

We stand behind our products, but cannot warrant against misuse

LIMITATIONS & LIABILITY

This warranty is exclusive and, where permitted by law, replaces all other express or implied warranties—including those of merchantability or fitness for a particular use.

Guntology assumes no responsibility for injury, damage, or malfunction resulting from:

- → Improper, illegal, or negligent us
- → Unauthorized alterations

- → Use with incompatible products or components
- → Unsafe mounting practices

Guntology will not be held liable for any incidental or consequential damages stemming from use, handling, or performance of our products.

WARRANTY SERVICE

To submit a warranty claim, contact us at

⊠ support@guntology.com

Subject: Warranty Claim - [Model Name]

We'll issue a Return Authorization (RA) number and instructions. Please do not return any product without prior approval. Valid claims include prepaid return shipping.